Connection to robair

Olivier Aycard

Grenoble INP - PHELMA
GIPSA Lab

 $\frac{ \text{https://www.gipsa-lab.grenoble-inp.fr/user/olivier.aycard}}{olivier.aycard@grenoble-inp.fr}$





- 1. ROS on robair (wireless connection: experimental);
- 2. ROS on robair (wired connection);
- 3. ROS on robair: how it works;
- 4. Tests of connection to robair.

Change the configuration: experimental wireless connection

- 1. You can run ROS nodes on your computer or on robair;
- 2. Move change_configuration.sh from ~/catkin_ws/data_for_labs to ~
- 3. To run nodes on your laptop: ~/change_configuration.sh local
 - Open a new terminal
- 4. To run nodes on one robair: ~/change_configuration.sh hotspot
 - Open a new terminal
- 5. To connect to a hotspot: robairx_hotspot
 - MDP: robairRobair42

- 1. ROS on robair (wireless connection: experimental);
- 2. ROS on robair (wired connection);
- 3. ROS on robair: how it works;
- 4. Tests of connection to robair.

Change the configuration: wired connection (1/4)

1. You can run ROS nodes on your computer or on robair;

```
student-3@robair: ~/Bureau
 FI.
Welcome to Ubuntu 20.04.3 LTS (GNU/Linux 5.11.0-37-generic x86_64)
                         Nodes are running on your computer
Configuration: local
student-3@robair:~/Bureau$
```


Change the configuration: wired connection (2/4)

1. You can run ROS nodes on your computer or on robair;

```
student-3@robair: ~/Bureau
 Ŧ
Welcome to Ubuntu 20.04.3 LTS (GNU/Linux 5.11.0-37-generic x86_64)
Configuration: robair
                         Nodes are running on robair
student-3@robair:~/Bureau$
```


Change the configuration: : wired connection (3/4)

1. To change your configuration, run switch_config.sh in ~



Change the configuration: : wired connection (4/4)

1. To change your configuration, run switch_config.sh in ~




- 1. ROS on robair (wireless connection: experimental);
- 2. ROS on robair (wired connection);
- 3. ROS on robair: how it works;
- 4. Tests of connection to robair.


ROS on robair (1/5)

- You must be connected to robair with a wire to run nodes on robair
- Roscore is running on robair:
 - You do not have to run "roscore" on your laptop
- Each robair publishes:
 - /scan (laserscanner data);
 - /odom (odometry).
- Each robair subscribes to:
 - /cmd_vel to command robair in translation and/or rotation.


ROS on robair (2/5)




ROS on robair (3/5)



ROS on robair (4/5)



ROS on robair (5/5)



- 1. ROS on robair (wireless connection: experimental);
- 2. ROS on robair (wired connection);
- 3. ROS on robair: how it works;
- 4. Tests of connection to robair.

Tests of connection on robair

- You do not have to run "roscore" on your laptop
 - Roscore is now on robair
- We will check if you are able to receive the laser data (/scan topic) and send motion to robair (/cmd_vel topic)
- 1. Open a terminal and run rviz
 - You should see the data of the laser scanner
- 2. Open a terminal and run "rosrun teleoperation teleoperation_node.py"
 - Use the keyboard to move robair
 - You should see robair moving